





Placing a Call

Enter a Number

1. Select **Place a Call** from the home screen, or just start entering the number on the remote control
2. Enter in the **IP address**, including the **dots**. Press the **keyboard**  key to enter text
3. Press  **Call** on the Remote Control


Using the Directory

1. Press  **Directory** on the remote
2. Highlight the contact you want to call. You can navigate to the contact or use the search field.
3. Press  **Call** on the remote control


Using Favorites or Recent Calls

On the **Favorites** or **Recent Calls** screen, select the contact or press the reference number that appears next to the contact.


Using Speed Dial

To call a speed dial contact from the home screen highlight it and press  **call** on the remote control.


Answer a Call

Press  **Call** or select yes using the remote control



End a Call

1. Press  **Hang up** on the remote control.
2. If prompt, confirm if you want to hang up

Adjust the Volume

Press  **Volume** on the remote control

Mute your Microphone

Press  Mute on the remote control or  on the table microphone.




Add a contact to the directory

From the Favorites or Directory screen, select **Options > Add a Contact**



Add to the Favorites List

- From the Favorites or Directory screen, select **Options > Add a Contact**
- From the recent calls screen or the global directory group in the directory, highlight a site, and select **Options > Add a Contact**.

Select or Adjust a Camera

1. If you are in a call, press  near or  far to select either the near-site or far-site control.
2. Press  Camera on the remote control, then select the camera or video source you want to use.
3. Press the arrow buttons on the remote control to pan or tilt the camera.
4. Press Zoom to zoom in or out.
- 5.

Power the System On and Off

- To power on the system, press the  Power button on the remote control or on the front of the system.
- To power off the system, press and hold the  Power button on the remote or on the front of the system for 2 (two) seconds. Wait 15 (fifteen) before you unplug the power cord

Video Conferencing Support:
e-Health Solutions Help Desk
1-877-666-3211

